

Our vision was to create a product that enhanced the user's experience. Crafted and engineered by experts in the Automatic Door industry.

**What's Included / Tech Specs:**

Micom single use accessible washroom kit (HWK-05-CPB-36) includes all the necessary devices that control the access and assistance of an accessibility washroom.


The interior / exterior column switches have illuminated "push" door activation as displayed in the images. The request for assistance button activates both an interior and exterior alarm. There's also an output option for a remote alarm.

The power supply provides a 12 VDC and 24 VDC output to power all modules in the kit and the lock release interface. (ie: electric latch retraction lock, electric strike or maglock).

The kit is designed to simplify the installation process and operation of the washroom door control functionality with direct connections to the control board with 3 - 30' plug in wire harness supplied as part of the kit.

**Included in the Kit:**

- 3-30' Plug and Play Wire Harnesses
- 3 column switches 38 1/2" x 6" x 1 1/2", Controller, RFA and Signage as shown below.



Meets latest requirements for Barrier Free Washroom.



CONTROLLER

WAIT FOR DOOR TO CLOSE  
  
 USE 'PUSH TO LOCK' SWITCH TO LOCK DOOR

Approach HAND to open  
 GREEN = Vacant RED = Occupied

Approach HAND to open  
 GREEN = Vacant RED = Occupied

IN THE EVENT OF AN EMERGENCY  
 PUSH EMERGENCY BUTTON  
 AN AUDIBLE AND VISUAL SIGNAL  
 WILL ACTIVATE  
 PULL TO RESET

# HWK-05-CPB-36

## All-in-One Universal Washroom Package.

### SEQUENCE OF OPERATION

- All 3 column switches are illuminated green in idle mode.
- Exterior "Push to Open" column switch activates door operator.
- Upon the door fully closed, activation of the "Push to Lock" column switch, door relay signals to energize the electric lock. All 3 column switches turn red. The system is in "Occupied" state.
- When the interior "Push to Open" column switch is activated the electric lock will be released, the automatic door opens, all 3 column switches turn to green
- When the Universal Washroom system is "Occupied", if the emergency push button is activated the door will unlock. The alarms will continue to make a sound and be lit until the push button is reset.

