



# Motor Gearbox Handing Orientation & Spring Pre-Load

RH/LHR Push

LH/RHR Push





Start @ 9 o'clock wind to 3 o'clock

Start @ 3 o'clock wind to 9 o'clock

RH Pull

LH Pull



Start @ 9 o'clock wind to 3 o'clock

Start @ 3 o'clock wind to 9 o'clock